




ROTARY PAPER CUTTER BLADES:



1) Unscrew Nut On Back Side.



2) Slide Safety Shield Down



3) Remove Blade

4) Replace Blade